

"can_spy_echo_example"

CAN Software Spy & Echo Example

AT90CAN32/64/128



Demo. program

Spy:

All frames of the CAN bus (echo frames included) are sent on the RS232 serial links of the DVK90CAB1 board (UART_0 & UART_1). «HyperTerminal» Windows can display them.



Terminal




Other node(s)



DVK90CAN1

"can_spy_echo_example"



"Echo"

CAN bus

Echo:

Each frame of the CAN bus (echo frames excepted) is re-sent with the following protocol:

- $ID_{echo} = ID_{received} + 1$
- 8-byte data frame
- 2 last bytes = CAN-STAMP register



CAN node
simulation



Demo. environment

■ IDE:

AVR Studio 4.13.528 (or higher)

AVRGCC plug-in

CAN plug-in

■ C Compiler:

WinAVR-20070122

■ Default target:

DVK90CAN1 Atmel development board

■ Configuration:

■ Software:




Described in «*config.h*» in main root

■ Hardware:

Described in «*..\libraries\lib_board\dvk90can_board.h*» (called by «*config.h*»)

■ Default setting:

- Microcontroller: **AT90CAN128** at **8 MHz** (external crystal - no internal RC)
- Both **UART_0** & **_1** available - baudrate: **38400** bds (8-bit, no parity, 1 stop-bit)
- CAN bitrate: **automatic detection** (both CAN 2.0A & 2.0B)
- Both Spy & Echo modes available



“CAN Rx & Tx” screen shot example

- ❑ If **no** key is pushed during RESET → **Spy & Echo** mode
- ❑ If **some** key is pushed during RESET → **Spy-only** mode
- ❑ CAN ID = 0 simulates a CAN Error

The screenshot shows the MiniMon V3 by IXXAT software interface. The main window displays a list of CAN messages with columns for Time / mSec, State, Mode, Identifier, and Data. A green arrow points to the top section of the message list, labeled "Spy & Echo mode". A blue arrow points to a smaller, inset window showing a subset of the messages, labeled "Spy-only mode". The status bar at the bottom indicates "Result of transmission: Opération réussie. [0x0]" and "Messages: 10".

Time / mSec	State	Mode	Identifier	Data
00:06:53.842	Self	29	1234..	00 11 22 33 44 55 66 77
00:06:53.869		29	1234..	00 11 22 33 44 55 02 84
00:06:57.325	Rtr Self	11	12	Remote request DLC = 5
00:06:57.349		11	13	00 11 22 33 44 00 2E 55
00:06:59.930	Self	11	66	DE AD BE EF
00:06:59.954		11	67	DE AD BE EF 00 00 C5 41
00:07:01.102	Rtr Self	29	700	Remote request DLC = 0
00:07:01.125		29	701	00 00 00 00 00 00 E2 29
00:07:02.177	Self	29	2006	28 03 20 06 18 33
00:07:02.202		29	2007	28 03 20 06 18 33 7E 19

Time / mSec	State	Mode	Identifier	Data
00:08:53.909	Self	29	1234..	00 11 22 33 44 55 66 77
00:08:55.746	Rtr Self	11	12	Remote request DLC = 5
00:08:56.932	Self	11	66	DE AD BE EF
00:08:58.454	Rtr Self	29	700	Remote request DLC = 0
00:08:59.716	Self	29	2006	28 03 20 06 18 33


Tx	ID	EXT	RTR	Data
<input checked="" type="checkbox"/>	123456	<input checked="" type="checkbox"/>	<input type="checkbox"/>	00 11 22 33 44 55 66 77
<input checked="" type="checkbox"/>	12	<input type="checkbox"/>	<input checked="" type="checkbox"/>	DLC = 5
<input checked="" type="checkbox"/>	66	<input type="checkbox"/>	<input type="checkbox"/>	DE AD BE EF
<input checked="" type="checkbox"/>	700	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	DLC = 0
<input checked="" type="checkbox"/>	2006	<input checked="" type="checkbox"/>	<input type="checkbox"/>	28 03 20 06 18 33

"can_spy_echo_example"

"Spy" screen shot example



Spy & Echo mode



```
CAN_spy - HyperTerminal
File Edit View Call Transfer Help
-0- ===== CAN SPY ECHO EXAMPLE ===== -0-

[AT90CANxx Library Version 3.20 / (R)]

-0- ===== UART in CAN ANALYZER ===== 0-
-0- RxCAN @ 0285: 0x12345678 (Ext.), L=8, 00-11-22-33-44-55-66-77
-0- RxCAN @ 97D7: 0x012 (Std.), L=5, Remote
-0- RxCAN @ C88F: 0x066 (Std.), L=4, DE-AD-BE-EF
-0- RxCAN @ B922: 0x00000700 (Ext.), L=0, Remote
-0- RxCAN @ 4E95: 0x00002006 (Ext.), L=6, 28-03-20-06-18-33

Connected 0:01:43 Auto detect 38400 8-N-2 SCROLL CAPS NUM Capture Print echo
```

```
CAN_spy - HyperTerminal
File Edit View Call Transfer Help
-0- ===== CAN SPY ECHO EXAMPLE ===== -0-

[AT90CANxx Library Version 3.20 / (R)]

-0- ===== Echo + UART in CAN ANALYZER ===== 0-
-0- RxCAN @ 0284: 0x12345678 (Ext.), L=8, 00-11-22-33-44-55-66-77
-0- TxCAN @ 2678: 0x12345679 (Ext.), L=8, 00-11-22-33-44-55-02-84
-0- RxCAN @ 2E55: 0x012 (Std.), L=5, Remote
-0- TxCAN @ 4DA8: 0x013 (Std.), L=8, 00-11-22-33-44-00-2E-55
-0- RxCAN @ C541: 0x066 (Std.), L=4, DE-AD-BE-EF
-0- TxCAN @ E50B: 0x067 (Std.), L=8, DE-AD-BE-EF-00-00-C5-41
-0- RxCAN @ E229: 0x00000700 (Ext.), L=0, Remote
-0- TxCAN @ 00F4: 0x00000701 (Ext.), L=8, 00-00-00-00-00-00-E2-29
-0- RxCAN @ 7E19: 0x00002006 (Ext.), L=6, 28-03-20-06-18-33
-0- TxCAN @ A00D: 0x00002007 (Ext.), L=8, 28-03-20-06-18-33-7E-19

Connected 0:01:12 Auto detect 38400 8-N-2 SCROLL CAPS NUM Capture Print echo
```

Spy-only mode

"can_spy_echo_example"



Atmel contact

Corporate Headquarters

2325 Orchard Parkway
San Jose, CA 95131,
USA
TEL: (1)(408) 441-0311
FAX: (1)(408) 487-2600

Asia

Room 1219
Chinachem Golden Plaza
77 Mody Road Tsimshatsui
East Kowloon
Hong Kong
TEL: (852) 2721-9778
FAX: (852) 2722-1369

Product Contact

La Chantrerie
BP 70602
44306 Nantes Cedex 3
France
TEL: (33) 2 40 18 18 18
FAX: (33) 2 40 18 19 60

Atmel customer support

E-mail

avr@atmel.com

Atmel products

Web site

www.atmel.com

